




# TF021001 Floor tub mixer



# **Installation Manual**

Installation / User Instructions / Warranty





# Thank you for Choosing MAXTOR



MAXTOR mission is to provide "design & quality that you can count on" bathroom products. MAXTOR's advantages to you:first-class bathroom products, fashion & enduring design, sustainable production and excellent service.MAXTOR's team will stick to our original intention, do a good job in every product, and serve every one of our customers wholeheartedly.

#### **Installation Considerations**

- MAXTOR recommends the faucet be installed by a licensed, professional plumber.
- Make sure read over the instructions throughly before installation, and you have all tools and supplies needed to complete the installation.
- Be sure to thoroughly flush the supply pipes of dirt and debris.
- Turn off the water supply before commencing work at the stop valve.
- This is the single hole basin faucet, not include deck plate, the deck plate should be bought seperately if install the faucet for three holes basin.
- Drain or a pull rod not be included also.
- d,professional plumber.

  allation, and you have all tools and

  abris.

  stop valve.

  the deck plate should be bought

  for use with 3/4 stops. If your stops
  bing supply store or home center. The hot and cold supply hoses included with this faucet are for use with \% stops. If your stops are a different size, pur-chase adapters at your local plumbing supply store or home center. Adapters are not available from MAXTOR.


### Care & Cleaning

A damp cloth and mild liquid dishwashing soap may be used, followed by rinsing with water and drying with a soft cloth. Most common household cleaners (including mild abrasives for Brushed Chrome and Platinum) can be used, when used in accordance with the manufacturers' instructions for use. However, all cleaners should be rinsed off thoroughly with water immediately after cleaning your faucet. Avoid using any harsh cleansers (e.g., steel wool or harsh chemicals) or pads/sponges that are unsafe for polished metallic surfaces. Most green, fibrous pads/sponges contain microscopic mineral particles that can scratch a faucet's finish. Cleaner manufacturers may change their formulations at any time; therefore, MAXTOR does not recommend any specific cleaner.

MAXTOR suggests the periodic application of a quality non-abrasive wax, such as car wax or furniture wax, especially for matte or textured finishes (e.g., Brushed gold, brushed Nickel Chrome or Chrome).

Removing Dried Water Spots:

A 50/50 blend of household vinegar and water can also be used for a limited amount of time, followed by rinsing with water and drying with a soft cloth.







Dwill





A R

Jilli Fillipei sc

Philiper screw driver Tape measure

nencil


Lavial

Teflon Tape


Silicone

#### 


## **Installation Steps**



Install the mounting box at the mixer installation location and adjust the position of the box using the level sensor.



Secure the mounting box to the floor with screws.




Connect the water pipes to the installation box.


Make sure the hot water supply is on the left and the cold water supply is on the right.

Fill the screed without removing the protective cover from the installation box.


Install the cladding (tiles).




Cut off the protruding part, seal the gap between the mounting box and the cladding with waterproof sealant.




Attach the waterproof plate.







Unscrew the screws and remove the plate with the level sensor.



Place the decorative reflector on the pipe and lift it up.



Screw the clamp onto the pipe and then secure it with a screw on the side.



Carefully install the pipe with the clamp into the water holes in the installation box.

Tighten the fastener with screws to the mounting box.




Move the valve to the "ON" position (open).


Lower the decorative reflector down.

Screw the hand shower to the hose and the hose to the faucet.

Check the operation of the mixer.



### **Hydraulic distribution**



Pressure(Bar)

## **Troubleshooting**

If you have followed the instructions carefully and your faucet still does not work properly, take the following coorective steps:

PROBLEM	CAUSE	ACTION
Leakage under the handle	Bonnet nut has come loose	Remove the cover button.Loosen screw with hex wrench . Remove the handle. Unscrew cap (by hand only). Tighten bonnet nut with an adjustable wrench. Remove the cartridge. Check for cracks
Aerator drips or has inconsistent water flow pattern	Aerator is dirty or not seated properly	Unscrew aerator with a coin/ Housing/integrated thread and clean out debris
Water will not shut off completely	Cartridge may need tobe adjusted or replaced	Remove the cover button.Loosen screw with hex wrench. Remove the handle. Unscrew cap (by hand only). Tighten bonnet nut with an adjustable wrench. Remove the cartridge. Check for cracks
Lower flow	The filter washer in thehose connectors or Aerator is dirty	Turn off the water supply at water valve and unscrew the hose connectors from water supply lines. Clean the filter washer in the water lines with hot water, removing any debris or calcium build up. Take off the aerator and clean it with hot water.

### **Limited Lifetime Warranty**

MAXTOR® provides our customers with an extensive warrant as a result of our excellent workmanship and high quality components used in our products.

Limited Lifetime Warranty: All parts of MAXTOR® faucet are warranted to the original consumer purchaser to be free from defects in material and workmanship for as long as the original consumer purchaser owns the home in which the faucet was first installed.

Surface finish warranty: A 5-years warranty is provided for all MAXTOR® faucet finishes to the original purchaser against manufacturing defects in workmanship.

Any labor charges incurred by the purchaser to repair, replace, install or remove this product are not covered by this warranty. MAXTOR Company shall not be liable for any damage to the faucet resulting from reasonable wear and tear, outdoor use, misuse (including use of the product for an unintended application), freezing water, abuse, neglect or improper or incorrectly performed installation, maintenance or repair, including failure to follow the applicable care and cleaning instructions. MAXTOR Company recommends using a professional plumber for all installation and repair.

What You Must Do To Obtain Warranty Service or Replacement Parts:

A warranty claim may be made and replacement parts may be obtained by contacting us by mail or online as follows (please include your model number and date of purchase):

Proof of purchase (original sales receipt) from the original purchaser must be made available to MAXTOR Company.

Or faucet with MAXTOR logo Pictures and "warranty card" picture(Each package with warranty card inside from MAXTOR company).